# **PreFormed™ Seat Installation Instructions**

## 1.0 PRODUCT & MATERIALS

- 1.1 Product: Seats are made from high-density expanded polystyrene with a liquid waterproof membrane finish. Seats are 100% waterproof and ready-to-tile.
- 1.2 Materials: Mortar mix for leveling pan area, ½" x ½" square notched trowel, latex modified thin-set and polyurethane sealant.

#### 2.0 PREPATORY WORK

- 2.1 Shower should be waterproofed in accordance with Tile Council of North America (TCNA) guidelines and all other applicable local codes before installing seat.
- 2.2 Ensure that walls are square and plumb for proper fit of seat.
- 2.3 Area where seat is to be installed must be level/free of slope in order for seat to fit the walls. Use leveling mortar mix in area where seat is to be installed. Test fit seat to ensure proper fit against wall area. Adjust as necessary.

## 3.0 INSTALLATION

- 3.1 Apply a medium bed, latex modified thin-set to the floor under and walls behind the seat. Use a  $\frac{1}{2}$ " x  $\frac{1}{2}$ " square notched trowel. Note: On the wall, trowel thin-set horizontally.
- 3.2 Slide seat in the thin-set, flattening the ridges and ensuring complete coverage of thin-set.
- 3.3 Once seat is installed, use a polyurethane sealant on all joints where seat meets the walls.
- 3.4 Install tile according to TCNA guidelines.

## For Technical Assistance Call Fin Pan, Inc. at 800-833-6444

SEAT MODELS - All seats are 20" in height

PF-402 / 16" x 16" Triangle PF-403 / 23" x 23" Triangle PF-404 / 16" x 16" Triangle Convex PF-408 / 15" Round PF-410 / 12" x 12" Square

Custom Seats and Benches Available - Call for Quote

\*PreFormed Component's Warranty will be voided if modified on the jobsite. Waterproofing should not be compromised. PreFormed Ready-To-Tile Components must be installed per Manufacturer's Instructions.