

**Ready for any job
... any situation.**

AND READY TO TILE IN MINUTES

ProPan™ Contractor Grade Shower Pans offer installers the ability to modify pans on-site. ProPan is designed to overcome on-site issues that may arise such as out of square walls, design changes and so on. ProPan can easily be cut down in size with a circular saw or even extended with ProPan 2' x 4' extensions.

ProPan adheres to industry standards with 1/4" per foot drain slope and comes standard with integrated drain assembly in the base. ProPan comes standard with the EBBE™ brand square drain and grate assembly for easier tiling. Every ProPan also includes a full foam curb assembly for on-site installation. An ADA shower ramp is also available for handicap showers.

ProPan is lightweight, waterproof and offers superior resistance to mold. It is constructed of high-density polystyrene and reinforced with fiberglass mesh and waterproof coating.

ProPan is available in shower kits which include ProPanel™ Lightweight Waterproof Backer Board, polyurethane sealant and fasteners. Custom shower pans are also available.

Together ProPan and ProPanel offer speed, ease of installation and a waterproof installation.



ProPan (with center drain installed)

Pan/Curb	48" x 48"	PRO-500	Pan/Curb	48" x 60"	PRO-503
Pan Kit	48" x 48"	PRO-KIT 500	Pan Kit	48" x 60"	PRO-KIT 503
Pan/Curb	36" x 60"	PRO-501	Custom	Call for quote	
Pan Kit	36" x 60"	PRO-KIT 501			
Pan/Curb	36" x 48"	PRO-502	Note:	Curb size is located on 2nd listed dimension. Drains available in PVC or ABS.	
Pan Kit	36" x 48"	PRO-KIT 502			

- ProPan Shower Pan Installation:**
1. Make sure subfloor is clean and level. Cut PVC/ABS drainpipe 1 3/8" below floor level.
 2. Remove strainer and test fit pan for fit and level before installing.
 3. Remove pan and apply a thinset to the floor area and underside of pan. Use a 1/2" x 1/2" notched trowel.
 4. Apply a PVC or ABS solvent cement to drain pipe and inside drain.
 5. Set pan into place and apply pressure to achieve complete coverage.
 6. ProPanel Backer Board or other: Apply a continuous 1/2" thick bead of polyurethane sealant into the perimeter channel of the

ProPan. Using 1/2" ProPanel or other backer board, set the board into sealant. Spread excess sealant ensuring a continuous seal at the joint.

7. Fasten ProPanel directly to framing with ProPanel fasteners starting 1 foot above the shower pan. Whenever 2 boards come together to make a joint, apply a 1/2" bead of sealant on board edges. All boards must be fitted together tightly allowing sealant to ooze from joint. Spread excess sealant ensuring a continuous seal at the joint.

NOTE: If using another type of backer board follow manufacturer's instructions.

8. Next, determine location of the ProPan Curb. Affix curb to floor by applying a 1/2" modified mortar bed to floor and underside of curb. Before setting curb in place, apply a bead of sealant to ProPan channel and to the adjoining wall panels.
 9. After installation is complete, it is specified to apply another bead of sealant on all joints, especially on the ProPan perimeter and curb, to fill any voids in sealant.
 10. All fasteners must be completely covered with sealant and spread to form a seal.
 11. Install tile.
- NOTE: It is the user's responsibility to ensure that the shower pan is waterproof prior to tiling.*

Find your niche and save time in the process.

PreFormed Niches unique in-wall construction can be used throughout the home for an added accent in foyers, kitchens, bar areas as well as the bathroom.

PreFormed Niches are made of one-piece construction and are waterproof. Niches can be installed and ready to tile in minutes, not hours.



Nominal dimensions of interior cavities

Niches		
Square	12" x 12"	PF-301
Wide Combo	12" x 12" & 6"	PF-304
Narrow Combo	8" x 12" & 6"	PF-305
Mega	12" x 20"	PF-306
Soap	8" x 8"	PF-308
Marble Shelves		
White (Dalmata)		PF-405
Beige (Botticino)		PF-406


NOTE: Shelves fit all 12" wide niches



FinPan The Strength Behind the Beauty.
Hamilton, OH • 800.833.6444 • www.finpan.com

PreFormed and ProPanel are trademarks of FinPan, Inc. ©Util-A-Crete and ProTEC Cement Backer Board are registered trademarks of FinPan, Inc. ©WaterTite is a registered trademark of the IPS Corporation.

- PreFormed Niche Installation:**
- Two Substrate Layers:**
1. Draw level pencil line on outside substrate layer.
 2. Place niche with the bottom of the box centered on the level line.
 3. Trace outline of the back of the niche box.
 4. Cut through both layers along line and remove panel.
 5. Place niche into opening.
- One Substrate Layer:**
1. Draw level pencil line on outside substrate layer.
 2. Place niche with the bottom flange of the box centered on the level line.
 3. Trace exterior flanges.
 4. Cut along line and remove panel.
 5. Caulk to cross bracing studs using a latex polymer liquid waterproof membrane or an adhesive that contains no VOCs.
- NOTE: PF-301, 304 and 306 are designed to fit 16" o.c. stud walls.*



Niches • Shower Pans • Shower Seats • Slopes • Curbs • Shelves • Pan Liners


Shower Pans

Shower Pans (with center drain installed)

Rectangle	32" x 60"	PF-110
Rectangle	34" x 48"	PF-111
Square	36" x 36"	PF-112
Rectangle	36" x 42"	PF-113
Rectangle	36" x 48"	PF-114
Rectangle	36" x 60"	PF-115
Square	42" x 42"	PF-116
Square	48" x 48"	PF-117

Custom Call for quote

Note: Curb is located on 2nd listed dimension. Drains available in PVC or ABS.



EBBE Polished Nickel EBBE Polished Chrome EBBE Brushed Nickel EBBE Rubbed Bronze

Easy to install. Ready to tile in minutes.

PreFormed Shower Pans get you in and out of the shower in a fraction of the time

required for traditional mud bed methods.

Both lightweight and waterproof, these shower pans are easier to install and offer superior resistance to mold.

PreFormed Shower Pans adhere to industry standards with 1/4" per foot drain slope, and come standard with integrated side splash, curb and drain assembly that have you ready to tile in just minutes.

Now offering EBBE Frameless Square Drain Grates.

You'll love the look and functionality that EBBE drain grates offer.

Slope, Curbs, and Shower Pan Liners

Slope

24" x 48" 3/4" x 1/4" taper PF-102

Curbs

48" PF-201

96" PF-202

Note: Curbs have 3 1/2" interior dimension

Shower Pan Liners

4' x 50' P445

6' x 50' P465

5' x 40' P455


4' x 100' P441

5' x 100' P451

6' x 100' P461

Shower Dam Corners SDC1

PVC Liner Cement (1 pint) P1066



Professional finish in minutes. Not Hours.

Waterproof PreFormed™ Underlayment

Components are easy to handle and install.

PreFormed Slopes are designed to comply with industry specified 1/4" sloped fill. It's never been easier to ensure proper slope and drainage. And these slopes eliminate a day of prep and screeding required for a minimally sloped mortar bed that goes under a traditional pan-liner.

WaterTite® Shower Pan Liners are a flexible polyvinyl chloride (PVC) membrane with a nominal thickness of 40 mil. WaterTite is used under full mortar bed installations for concealed waterproofing.

PreFormed Curbs' unique design is ideal for traditional 2' x 4' installation. They are durable and watertight. And versatile -- PreFormed Curbs can also be used for knee walls and countertop edges.

Shower Seats

Seats

Triangle 16" x 16" PF-402

Triangle 23" x 23" PF-403

Triangle-Convex 16" x 16" PF-404


Round 15" diameter PF-408

Square 12" x 12" PF-410

Custom Call for quote

Note: All seats are 20" high

We'll save you a seat. PreFormed Seats are sturdy and waterproof, made of high-density polystyrene and a latex polymer liquid waterproof coating. These seats install in a fraction of the time required for traditional methods.



FinPan

Each of Our PreFormed Components Are Waterproof, Lightweight, Easy to Install & Ready to Tile in Minutes!

And We Make It Last.

For a tile work of art that will truly last a lifetime, be sure to use Util-A-Crete® or ProTEC® Cement Backer Board, and ProPanel™ Lightweight Backer Board from FinPan, Inc.

For more information on the complete line of FinPan building products, visit our website at www.finpan.com.

PreFormed Shower Pan Installation:

1. Before installation, plug the drain pipe from the bottom and fill shower pan with water for 24 hours to ensure there are no leaks. If leaks occur, repair with latex polymer liquid waterproofing supplied with pan.
2. Make sure subfloor is clean and level. Cut PVC floor drainpipe 5/8" above floor level.
3. Remove strainer and line up access to drainpipe from above.
4. TEST shower pan for fit and level before installing.
5. Remove pan and apply thinset with 1/2" x 1/2" square notch or 19/32" half moon trowel. Cover area below pan thoroughly.
6. Apply PVC or ABS solvent cement to drain

pipe and inside drain.

7. Set pan into wet thinset and press firmly for solid contact.
8. Seal joint between backerboard and shower pan.
9. Install tile.

NOTE: It is the user's responsibility to ensure that the shower pan is waterproof prior to tiling.

PreFormed Slope Installation:

1. Measure and locate center of shower pan drain. Measure from center of the drain to shower corners.
2. Cut pre-slope panels to length. Cut slopes from the 1/4" edge toward the 3/4" edge.
3. Cut around drain flange and position all pieces.
4. Secure PreFormed Slopes to sub-floor with Latex Polymer Liquid Waterproof Membrane.

5. Using TCNA and membrane manufacturer's specified methods, install PVC pan liner, liquid-applied waterproof membrane or other acceptable waterproof membrane over the PreFormed Slope and up the wall 3" above the curb.
6. Plug the inside of the drainpipe and fill the shower pan with water for 24 hours. Repair any leaks before proceeding.
7. Float a 1 1/2" mortar bed on top of the

waterproof membrane using a standard floor mud. Let cure for 24 hours.

PreFormed Curb Installation:

1. Install waterproof membrane or pan liner over 2" x 4" curb structure..
2. Cut curb to dimension of opening.
3. Coat inside of curb with thinset mortar and place over pan liner.
4. Install tile.

PreFormed Shower Seat Installation:

1. Dry fit the seat to be sure it fits snug against the walls. The walls must be square and plumb.
2. Remove seat and completely waterproof the wall and floor behind the seat with a latex polymer liquid waterproof membrane. Allow the latex membrane to completely dry.
3. Apply a polymer modified portland cement medium bed thinset to the wall and floor behind with a 1/2" x 1/2" square notch or 19/32" half-moon trowel. NOTE: on the wall, trowel the mortar horizontally, slide the bench in the mortar using the NTCA trowel and embed into the mortar on the floor, achieving complete coverage.
4. Once the thinset is set, tape all of the seams of the bench with fiberglass reinforced mesh and latex membrane.
5. Install tile.

NOTE: PreFormed Shower Seats are waterproof. It is important that the outside coating remains intact and undamaged. Do not cut the shower seat. This will void all warranties.